

군산대 12월 1일 발표


Preparing Metal Chalcogenide Quantum Dot (QD) Photosensitizers for Photoelectrochemical Applications

(광전기화학적 응용을 위한 금속 칼코게나이드 양자점
광감응제 준비)

Hyo Joong Lee

(Dept. of Chemistry, JBNU)

Scheme 1.



What
else?

? ? ?

How to select?


Dipping
time

Solvent



Precursor

Solution's pH

Concentration



$\text{Cd}(\text{NO}_3)_2$ vs $\text{Cd}(\text{Ace})_2$



SILAR 5








Figure 1(a)

전구체 and pH



4가지의 pH 값 (~6.5 pH)

Dipping time




Figure 3

용매 조건-EtOH




Figure 4(a)




Figure 4(b)

Figure 5






Figure 6










Table 1

J-V 데이터 통계 처리 (평균/표준편차)

	J_{sc} (mA/cm ²)	V_{oc} (V)	FF	PCE (%)
(1) 0.1 M Cd(NO ₃) ₂	4.10 ± 0.26	0.62 ± 0.01	0.55 ± 0.02	1.39 ± 0.07
(2) 0.1 M Cd(CH ₃ COO) ₂	7.41 ± 0.41	0.65 ± 0.01	0.51 ± 0.02	2.49 ± 0.27
(3) 0.1 M Cd(CH ₃ COO) ₂ with 1.0 M TEA	10.14 ± 0.25	0.63 ± 0.02	0.51 ± 0.01	3.27 ± 0.11



실험 과정 2



Schematic diagram showing how to make the Sb₂S₃-sensitized solid-state cell.


ZnS 최대 흡착 조건 찾기

실험 방법

전극	Abs용 TiO ₂ 전극 (Tape 1 layer)		
	Solution	pH of cationic solution	SILAR (2)
Zn ²⁺ 용액	① 0.1M Zn(ace) ₂ ·2H ₂ O in H ₂ O	6.1	<div><div><div>(+)</div><div>(+)용매</div></div><div>→</div><div><div>⑥(-)</div><div>(-)용매</div></div></div> <div><div>60s</div><div>60s</div><div>60s</div><div>60s</div></div>
	② 0.1M Zn(ace) ₂ ·2H ₂ O in H ₂ O/MeOH (v/v=1:1)	5.8	
	③ 0.1M Zn(ace) ₂ ·2H ₂ O + 0.1M TEA in H ₂ O	6.4	
	④ 0.1M Zn(ace) ₂ ·2H ₂ O + 0.2M TEA in H ₂ O	6.8	
	⑤ 0.1M Zn(ace) ₂ ·2H ₂ O + 1.0M TEA in H ₂ O	9~11	
S ²⁻ 용액	⑥ 0.1M Na ₂ S·9H ₂ O in H ₂ O		
Pb ²⁺ 용액	⑦ 0.1M Pb(NO ₃) ₂ in H ₂ O		Dipping for 5min and washing (H ₂ O→EtOH)

용액 및 흡착 결과

용액



흡착 결과

	(+)용액
①	Zn(ace)_2 in H_2O
②	Zn(ace)_2 in $\text{H}_2\text{O/MeOH}$
③	Zn(ace)_2 + 0.1M TEA in H_2O
④	Zn(ace)_2 + 0.2M TEA in H_2O
⑤	Zn(ace)_2 + 1.0M TEA in H_2O




TEA를 많이 첨가할수록 용액이 뿌옇게 변함
그러나 흡착 결과를 보면 SILAR 2회에도 불구하고
1.0M TEA를 첨가한 양이온 용액 사용시 매우 어두운 색
을 띠는 것을 확인.

*양이온 용액에 의한 변화를 확인하기 위해 음이온 용
액은 동일한 조건으로 사용함.


전극	Abs용 TiO ₂ 전극 (Tape 1 layer)				
	Solution		pH of cationic solution	SILAR (2)	
Zn ²⁺ 용액	① 0.1M Zn(ace) ₂ ·2H ₂ O + 1.0M TEA in H ₂ O		About ~9	<div><div>(+)</div><div>(+) 용매</div><div>H₂O / MeOH (1:1)</div><div>→</div><div>③ (-)</div><div>(-) 용매</div></div>	
	② 0.1M Zn(NO ₃) ₂ ·6H ₂ O + 1.0M TEA in H ₂ O				
S ²⁻ 용액	③ 0.1M Na ₂ S·9H ₂ O in H ₂ O/MeOH (v/v=1:1)			60s	60s
Pb ²⁺ 용액	④ 0.1M Pb(NO ₃) ₂ in H ₂ O			Dipping for 5min and washing (H ₂ O→EtOH)	

	(+)용액
①	Zn(ace) ₂ + 1.0M TEA in H ₂ O
②	Zn(NO ₃) ₂ + 1.0M TEA in H ₂ O

①용액은 뿌옇고, ②용액은 투명하며 가라앉는 것도 없다.




바닥에 대고 찍은 사진



공중에 들어서 찍은 사진

*①, ②용액 모두 비슷한 색을 나타냄

흡수 스펙트럼 (Absorbance)




Absorbance spectra of PbS films prepared by cation exchange process between Zn²⁺ and Pb²⁺ after ZnS SILAR process repeated three times using different Zn²⁺ solutions: (1) 0.1 M Zn(NO₃)₂ in H₂O, (2) 0.1 M Zn(CH₃COO)₂ in H₂O, (3) 0.1 M Zn(CH₃COO)₂ in H₂O/MeOH, and (4) 0.1 M Zn(NO₃)₂ in H₂O with 1.0 M TEA. The inserted picture shows a bare TiO₂ film and each corresponding film.

전류-전압 곡선 (J-V)

	ZnS SILAR	Sb ³⁺ 용액 dipping time	Reverse scan with mask			
			Jsc	Eoc	FF	CE
1	8회	5 min	7.677	0.4190	0.4156	1.337
2	10회		9.180	0.4240	0.4240	1.650
3	12회		9.256	0.4350	0.4381	1.764

IPCE 측정



바닥에 놓고 찍은 사진




~300°C 가열 전

공중에 들고 찍은 사진



~300°C 가열 후




양이온 교환 조건

	ZnS SILAR	Sb ³⁺ 용액 dipping time	Reverse scan with mask			
			Jsc	Eoc	FF	CE
1	12회	5 min	9.036	0.4370	0.3980	1.572
2		10 min	8.529	0.4180	0.4325	1.542
3		3 min at 40°C	9.764	0.4480	0.4330	1.894
4		5 min at 40°C	9.630	0.4540	0.4527	1.979

바닥에 놓고 찍은 사진




~300°C 가열 전



~300°C 가열 후


공중에 들고 찍은 사진



*1~4번 전극 색은 큰 차이가 없으나 1번 전극의 색이 살짝 더 진하게 보임


*Sb³⁺용액을 40°C로 가열하면서 이온 교환을 시키면 확실히 빠르게 색 변화가 일어남

XRD 데이터



XRD pattern of FTO/TiO₂ and FTO/TiO₂/Sb₂S₃ films. The asterisk indicates the main peaks of Sb₂S₃.

효율 추적 및 J-V(처음 vs 최대 효율) & IPCE



(a) Changes in efficiency tracked for about one month, (b) J-V curves showing enhanced photovoltaic performance compared to initial measurements, and (c) IPCE of a Sb_2S_3 -sensitized solid-state cell. The inserted table in part (b) shows (1) initial and (2) enhanced photovoltaic parameters of the solar cell.